




IMPORTANT SAFETY NOTES




ALWAYS READ THE INSTRUCTIONS BEFORE USING PODIUM




NEVER USE A PODIUM WITH DAMAGED OR MISSING COMPONENTS




NEVER OVERREACH




NEVER HAVE MORE THAN ONE PERSON ON THE PLATFORM




NEVER USE ON UNEVEN OR SLOPING SURFACES




DO NOT MOVE PODIUM IF A PERSON IS STILL ON IT



NEVER USE BOXES FOR EXTRA HEIGHT, STAND ONLY ON THE PLATFORM




NEVER USE PODIUMS AS A MEANS OF ACCESS TO ANOTHER PLACE.



NEVER USE PODIUMS NEAR ELECTRICAL POWER LINES


BE AWARE OF THE FOLLOWING:-

- A. DO NOT USE ON LOOSE OR SLIPPERY SURFACES.
- B. NEVER STAND ON THE ACCESS LADDER TO WORK.
- C. WORKING PLATFORM MUST BE LEVEL.
- D. INSPECT BEFORE USE.
- E. ONLY ASCEND OR DESCEND THE LLWP USING THE ACCESS PROVIDED.
- F. FACE THE FOLDING BACK SECTION WHEN ASCENDING OR DESCENDING.
- G. ENSURE THE GATE IS CLOSED AND LOCKED BEFORE USE.
- H. BEWARE OF FINGER TRAPS.
- J. TO MOVE UNIT UNLOCK GATE AND DISMOUNT, UNLOCK CASTORS AND RE-LOCATE.
- K. IF IN DOUBT DO NOT GUESS CONSULT YOUR SUPPLIER.
- L. SEE OVERLEAF FOR COMPONENT CHECKLIST



ALWAYS LOCK ALL CASTORS WHEN PODIUM IS SITED, AND BEFORE USE.

1500 AND PAS 250 1500 PODIUM UNIT ASSEMBLY GUIDE



Dimensions — Platform at 1.5M x Width —0.85M x Depth 1.3M
 Working Height — 3.5M (Max)
 Dimensions — Folded Height —2.5M x Width - 0.25M x Depth - 1.3M
 Weight—42kg
 Safe Working Load - 150kg
 Manufactured under an ISO9001:2008 Quality System
 Complies fully with the Working at Height Regulations 2005 and PAS250
 Specifications when fitted with stabilisers
 Lightweight all Aluminium Construction

For further information or assistance, please contact
 Interlink Alloy Systems Limited—Tel 01992 716509
 Or visit: www.interlinkalloy.co.uk

1500 AND PAS 250 1500 PODIUM UNIT ASSEMBLY GUIDE



- 1 X FOLDING FRAME
- 1 X PLATFORM
- 1 X DIAGONAL BRACE
- 1 X LADDER
- 2 X STABILISER
- (FOR PAS 250 COMPLIANCE)



1) OPEN FRAME AND LOCK MECHANISM



2) FIT PLATFORM AT CORRECT HEIGHT



3) FIT DIAGONAL BRACE



4) CLIP UPPER BRACE OF LADDER ABOVE RINGS ON VERTICALS WITH ASSEMBLED HOOKS ON TOP



5) POSITION UNIT AND LOCK CASTORS



6) DEPLOY STABILISERS IN CORRECT POSITION



7) USE LADDER TO ACCESS PLATFORM



8) CLOSE AND LOCK GATE